



Customer Guide

Office: (325) 658-8375 Monitoring Station: 1 (866) 658-8375

Arm Away

Will arm **all** devices.

Press buttons
in this order:



*If not on
"Home Page"



Security



Away



Enter 4
Digit PIN
(If needed)

Arm Stay

To **stay** in the home or building.
Will **not** arm motion detectors.

Press buttons
in this order:



*If not on
"Home Page"



Security



Stay



Enter 4
Digit PIN
(If needed)

Disarm the System

Deactivate alarm.

Press buttons
in this order:



*If not on
"Home Page"



Security



Disarm



Enter 4
Digit PIN
(If needed)

Emergency

Authorities dispatched immediately.

Press buttons
in this order:



Press and **hold**
for **three seconds**
the associated icon:

- FIRE
- PANIC
- SILENT PANIC
- MEDICAL

Brightness/Volume

Adjust screen brightness and
kepad volume.

Press buttons
in this order:



*If not on
"Home Page"



Adjust:
BRIGHTNESS
or **VOLUME**
accordingly.

Chime/Voice Alerts

To turn chime and voice alerts on
and off.

Press buttons
in this order:



*If not on
"Home Page"



Enter 4
Digit PIN



Adjust:
CHIME or **VOICE**
accordingly.

Zone List



*** Press to return to the “Home Page”.**



**** Home Page**