



Office: (325) 658-8375
Monitoring Station: 1 (866) 658-8375

Arm Away

Will arm **all** devices.

Press buttons
in this order:



+



+

Enter 4
Digit PIN

Arm Stay

To **stay** in the home or building.
Will **not** arm motion detectors.

Press buttons
in this order:



+



+

Enter 4
Digit PIN

Disarm the System

Deactivate alarm.

Press buttons
in this order:



+

Enter 4
Digit PIN

Emergency

Authorities dispatched immediately.

Local Alarm

Sound siren only; no dispatch.

Press and **hold**
for three
seconds:



+



FIRE



POLICE



SIREN ONLY;
NO DISPATCH

Chime/Voice Alerts

To turn chime on and off.

Press buttons
in this order:



SETTINGS

+

Select:
CHIME or **VOICE**
and adjust settings
accordingly.

+

Select:
SAVE

