



Office: (325) 658-8375  
Monitoring Station: 1 (866) 658-8375

## Arm Away

Will arm **all** devices.

Press buttons  
in this order:

Enter 4  
Digit PIN  
\*Green "ready" light  
must be ON.

+

**2** AWAY  
Arm Away

\*If green ready light is **not on**, press "\*" to locate open zones. Close open zones, and try again.

## Arm Stay

To **stay** in the home or building.  
Will **not** arm motion detectors.

Press buttons  
in this order:

Enter 4  
Digit PIN  
\*Green "ready" light  
must be ON.

+

**3** STAY  
Arm Stay

\*If green ready light is **not on**, press "\*" to locate open zones. Close open zones, and try again.

## Disarm the System

Deactivate alarm.

Press buttons  
in this order:

Enter 4  
Digit PIN

+

**1** OFF  
Off

To clear alarm memory, follow this procedure two times.

## Panic/Duress

Authorities dispatched immediately.

Press buttons  
in this order:



Enter 2580

+

**1** OFF  
Off

## Door Chime

To turn chime on and off.

Press buttons  
in this order:

Enter 4  
Digit PIN

+

**9** CHIME

**Zone List**

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---



---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---



Office: (325) 658-8375  
Monitoring Station: 1 (866) 658-8375